



Epson Premium Glossy Photo Paper

Glossy - 100 x 150 mm 40 sheet(s) photo paper - for EcoTank ET-2650 - 2710 - 2712 - 2714 - 2715 - 2720 - 2721 - 2726 - 2750 - 2751 - 2756 - 4700 - 4750

Group	Print Media
Manufacturer	Epson
Manufacturer item no.	C13S042153
EAN/UPC	8715946384337

Description

Five golden stars for the highest requirements. Go for the highest printing standards with this high-quality photo paper. With a grammage of 255g/m², this paper provides the best performance and durability for professional use. Choose the best quality with five golden stars.

Main features

Product Description	Epson Premium Glossy Photo Paper - photo paper - glossy - 40 sheet(s) - 100 x 150 mm
Product Type	Photo paper
Surface Finish	Glossy
Media Size	100 x 150 mm
Printing Technology	Ink-jet
Included Qty	40 sheet(s)
Compatible with	EcoTank ET-16500, 2600, 2650, 2710, 2711, 2712, 2714, 2715, 2720, 2721, 2726, 2750, 2751, 2756, 3750, 4700, 4750, 7700, 7750; Expression Home XP-245, 247, 342, 345, 442, 445; Expression Home HD XP-15000; Expression Premium XP-540, 6000, 6005, 640, 645, 900; SureColor P800; WorkForce WF-2760, 3620

Extended details

Media

Media Type	Photo paper
Surface Finish	Glossy
Media Sizes	100 x 150 mm
Printing Technology	Ink-jet
Included Qty	40 sheet(s)

Compatibility Information

Compatible with	Epson L130, L220, L310, L355, L365, L555, L565, L655, L810, MUFC Printer Epson B 300, 500DN Epson EcoTank ET-14000, ET-16500, ET-2600, ET-2650,
-----------------	---



ET-2650 Unlimited, ET-2710, ET-2710 Unlimited, ET-2711, ET-2712, ET-2714, ET-2715, ET-2720, ET-2720 All-in-One Supertank Printer, ET-2720 Unlimited, ET-2721, ET-2721 Unlimited, ET-2726, ET-2750U, ET-2751, ET-2756, ET-3750, ET-4500, ET-4700, ET-4700 Unlimited, ET-4750, ET-4750 Unlimited, ET-4750U, ET-7700, ET-7750 | Epson Expression Home XP-102, XP-202, XP-205, XP-212, XP-215, XP-225, XP-235, XP-245, XP-247, XP-30, XP-305, XP-312, XP-315, XP-322, XP-325, XP-342, XP-345, XP-402, XP-405, XP-415, XP-422, XP-425, XP-432, XP-435, XP-442, XP-445, XP-530 | Epson Expression Home HD XP-15000 | Epson Expression Photo XP-55, XP-750, XP-760, XP-850, XP-860, XP-950, XP-960 | Epson Expression Premium XP-530, XP-540, XP-540 Media Bundle, XP-6000, XP-6005, XP-605, XP-610, XP-615, XP-620, XP-630, XP-635, XP-640, XP-645, XP-810, XP-900, XP-900 Stickers | Epson PictureMate Dash PM 260 | Epson PictureMate Zoom PM 290 | Epson Stylus C91, CX4300, Pro 3880, Pro 3880 Mirage Edition, S21, SX110, SX115, SX130, SX210, SX215, SX235W, SX410, SX415, SX435W, SX445W, SX510W, SX515W, SX535WD, SX610FW, T26, T27, T59, TX106, TX109, TX117, TX119, TX200, TX209, TX210, TX219, TX400, TX409, TX410, TX419, TX550W | Epson Stylus Color 900PS | Epson Stylus Office B40W, B42WD, BX300F, BX305F, BX310FN, BX320FW, BX600FW, BX610FW, BX635FWD, BX925FWD, T1100, T30, T40W, TX300F, TX510FN, TX600FW | Epson Stylus Photo 1500W, PX650, PX660, PX700W, PX710W, PX730WD, PX810FW, PX830FWD, R2000, R295, T50, TX650, TX700W, TX710W, TX800FW | Epson SureColor P400, P800 Designer Edition, SC-P400, SC-P800 | Epson WorkForce WF-100W, WF-2010W, WF-2630, WF-2630WF, WF-2650DWF, WF-2660DWF, WF-2750DWF, WF-2760DWF, WF-3620DWF, WF-3620DWF Stickers, WF-3640DTWF, WF-7110DTW, WF-7515, WF-7610DWF | Epson WorkForce Pro WF-4630DWF, WF-4640DTWF

Technical data © CNET Content Solutions. Subject to technical modifications and errors.