


Epson Premium Semigloss Photo Paper

Semi-glossy - 100 x 150 mm - 251 g/m² - 50 sheet(s) photo paper - for EcoTank ET-2750 - 2751 - 2756 - 2850 - 2851 - 2856 - 4750 - 4850; Expression Home HD XP-15000

Group	Print Media
Manufacturer	Epson
Manufacturer item no.	C13S041765
EAN/UPC	0010343605169



Description

Premium Semigloss Photo Paper (250) delivers highly saturated prints by offering maximum ink coverage and a high D-Max for true photographic reproductions. Its 265 micron resin coated base gives prints a photographic feel, and keeps the paper cockle-free. Ideal for use with all Epson Inks. Like all Epson innovative media, this paper is engineered to give you the highest resolution and colour saturation possible. As always, Epson supplies guarantees Epson quality. Overview- Highest colour gamut available for vivid colour reproduction- Resin coated paper base for actual photo prints- Semigloss finish- Enhanced 2880 dpi printing for the highest quality output- Dries instantly for easy handling (using Epson inks)- Compatible with UltraChrome ink- 265 micron thickness for a durable photographic feel.

Main features

Product Description	Epson Premium Semigloss Photo Paper - photo paper - semi-glossy - 50 sheet(s) - 100 x 150 mm - 251 g/m ²
Product Type	Photo paper
Surface Finish	Semi-glossy
Media Size	100 x 150 mm
Printing Technology	Ink-jet
Media Weight	251 g/m ²
Included Qty	50 sheet(s)
Compatible with	Epson L655, L805; EcoTank ET-2750, 2751, 2756, 2850, 2851, 2856, 3750, 4750, 4850, 7700, 7750; Expression Home HD XP-15000; Expression Premium XP-540, 6000, 6005, 640, 645, 900; SureColor P400, SC-P400; WorkForce WF-2750, 2760, 3620; WorkForce Pro WF-6090, 6590, R5190, R5690, R8590, R8590 D3TWFC

Extended details

Media	
Media Type	Photo paper
Surface Finish	Semi-glossy
Media Sizes	100 x 150 mm
Printing Technology	Ink-jet
Included Qty	50 sheet(s)
Media Weight	251 g/m ²

Compatibility Information

Compatible with

Epson L130, L220, L310, L355, L365, L555, L565, L655, L805, L810 | Epson EcoTank ET-2750, ET-2750U, ET-2751, ET-2756, ET-2850, ET-2850U, ET-2851, ET-2856, ET-3750, ET-4750, ET-4750 Unlimited, ET-4750U, ET-4850, ET-4850U, ET-7700, ET-7750 | Epson Expression Home XP-320, XP-33, XP-420, XP-424, XP-530 | Epson Expression Home HD XP-15000 | Epson Expression Photo XP-55, XP-750, XP-760, XP-850, XP-860, XP-950, XP-960 | Epson Expression Premium XP-530, XP-540, XP-540 Media Bundle, XP-6000, XP-6005, XP-605, XP-610, XP-615, XP-620, XP-630, XP-635, XP-640, XP-645, XP-810, XP-900, XP-900 Stickers | Epson PictureMate 100, 260 | Epson Stylus C43SX, C45, C48, C87, CX3500, CX3700, CX4700, CX4900, CX5900, CX6400, CX6600, D120, D88, D88 Plus, D92, DX3800, DX3850, DX4400, DX4450, DX4850, DX7400, DX7450, DX8400, DX8450, DX9400F, Pro 3880, S20, S21, SX100, SX105, SX110, SX115, SX130, SX200, SX205, SX210, SX215, SX235W, SX400, SX405, SX410, SX415, SX435W, SX445W, SX510W, SX515W, SX535WD, SX600FW, SX610FW | Epson Stylus Office B1100, B40W, B42WD, BX300F, BX305F, BX310FN, BX320FW, BX600FW, BX610FW, BX635FWD | Epson Stylus Photo 1290, 1290S, 1400, 1500W, PX650, PX660, PX700W, PX710W, PX730WD, PX810FW, PX830FWD, R1800, R1900, R2000, R220, R240, R2400, R285, R2880, R3000, R320, R340, R800, RX500, RX520, RX585, RX600, RX620, RX685, RX700 | Epson SureColor P400, P600, SC-P400, SC-P600 | Epson WorkForce WF-100W, WF-2010W, WF-2630, WF-2630WF, WF-2650DWF, WF-2660DWF, WF-2750DWF, WF-2760DWF, WF-3620DWF, WF-3620DWF Stickers, WF-3640DTWF, WF-7110DTW, WF-7515, WF-7610DWF | Epson WorkForce Pro WF-4630DWF, WF-4640DTWF, WF-6090DW, WF-6590DWF, WF-R5190 DTW Flex, WF-R5190 DTW Flex BAM, WF-R5690 DTWF Flex BAM, WF-R5690DTWF Flex, WF-R8590 D3TWFC Flex, WF-R8590 DTWFC Flex, WF-R8590DTWF Flex

Technical data © 1WorldSync. Subject to technical modifications and errors.