



Toshiba Scrapper 371

Gruppe	Zubehör Drucker
Hersteller	Toshiba
Hersteller Art. Nr.	6LA79618000

Beschreibung

TOSHIBA	E-STUDIO
163/165/166/167/181/182/195/200/202/203/205/206/207/212/223/225/230/232/233/237/242/245/255/256/280/282/283/305/306/355/356/455/456/506	
DRUM PICKER FINGER, TOSHIBA	E-STUDIO
163/165/166/167/181/182/195/200/202/203/205/206/207/212/223/225/230/232/233/237/242/245/255/256/280/282/283/305/306/355/356/455/456/506	
DRUM PICKER FINGER	

Ausführliche Details

Allgemeines

Typ	Sonstiges Druckerzubehör
-----	--------------------------